Separation of isotopes

By

Jan Ove Odden and Dag Øistein Eriksen
Kristiansand, 2006

Isotopes in general

- Atoms of the same element with *different numbers of neutrons* are called isotopes
- Most common isotope of hydrogen has no neutrons at all
- The second isotope of hydrogen has one neutron – deuterium
- The third isotope has two neutrons - tritium

Hydrogen

Deuterium

Tritium

Isotopic distribution of silicon:

The distribution of the three different silicon isotopes in the nature is:

$^{28}Si \approx 92\ \%$ $^{29}Si \approx 5\ \%$ $^{30}Si \approx 3\ \%$



This isotopic distribution is also seen in end products like silicon-chips

Different isotope separation techniques:



Separation Nomenclature

- Isotope separation, enrichment & depletion are concepts used when the concentration of a specific isotope is altered from its natural occurrence

- The enrichment factor (beta) is a measure of the separation of isotopes
  - Beta = 1 No separation took place
  - Beta > 1 Indicates enrichment
  - Beta < 1 Indicates depletion

- The cut (theta) is a measure of the amount of feed that ends up in the product stream

- The beta and the cut are the determining factors defining the size and cost of a plant

Separating Unit, Stage and Cascade

- *Separating Unit* is the smallest element of a plant that effects separation – single centrifuge, ASP single stationary wall pipe

- A *Stage* is a group of parallel-connected separating units that is fed the same composition and produces product streams with the same composition

- Stages are connected in series until the desired separation between product and waste is achieved. This is known as a *Cascade*

Cascade Enrichment

- Separating Element



- Simple Cascade



- Recycle Cascade



4-up 1-down Cascade



Separation Nomenclature, continue

- Separative Working Unit (SWU) is the amount of separation work done by a cascade to obtain one unit of product of the desired enrichment

- The specific energy consumption (E/δu) is the amount of energy needed to produce one SWU. For instance if the cost of electricity is $0.03 per kWh, then for a E/δu=1000 the electricity cost would be $30 per SWU.

Laser Isotope Separation

- When different isotopes have slightly different levels of excitation
- Radiation of the right frequency must be available
- The excited species must have the ability to be easily separated
- The selectivity for the desired isotope must be good
- Still to complex to be used industrially

Laser-based isotope enrichment of Carbon 12/13:

Different separation techniques based on centrifugation:

Rosegard Vortex Extraction

October, 1976

Enrichment: 1.056 (Argon)

Cut: 6-8%







Wikdahl Vortex Separation



March, 1976:

Enrichment: 1.023

Cut: 50%

UCOR Vortex Process

- Enrichment is achieved under pressurized conditions by centrifugal means in a stationary-wall centrifuge



1975 – 1990:

Enrichment: 1.03

Cut: 5%

NO PATENT

Separation based on chromatographic methods

Theory on diffusion of gaseous species through the chromatographic column:

Fick's 1st law: $J_x = -D_x \frac{\partial c}{\partial x}$, the flux (J) along the direction x is proportional to the concentration (c) gradient. D is the diffusion coefficient.

Fick's 2nd law: $\frac{\partial c}{\partial t} = D_x \frac{\partial^2 c}{\partial x^2}$, when D is constant.

The compound containing 3 isotopes is released at time t=0.



Distribution at t=1



Distribution at t=4

Results: Chemical separation



ISOSILICON

Results: Chemical separation



Conclusion:

- *The retention of silane is not of kinetic nature since argon is heavier than silane and should therefore move slower.*
- *The retention must be due to molecular interactions between the porous material in the column and silane.*

Results: Mass separation – selectivity coefficient



$$\alpha_{33}^{29} = \frac{I_{29}}{I_{33}}$$, α is the selectivity coefficient

$$I_i = \frac{\int_{t_1}^{t_2} c_i(L,t)dt}{\int_{0}^{\infty} c_i(L,t)dt}$$

α is calculated from the ratio of the

areas under the flanks of the mass distribution

Results: Mass separation – selectivity







Separation factors in the order of 1.10 is possible, but on the expense of the yield